

Az érintőgombos csaptelep használata



Hideg víz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék tisztított, hűtött vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.



Szódavíz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék tisztított, hűtött, szénsavas vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.



Forró víz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék 85 °C-os hőmérsékletű tisztított vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.

Rámelegítés / Beállítások

Kérjük, használja a készüléket ECO üzemmódban.

- Rámelegítéshez nyomja meg egyszer a beállítás gombot.
- Nyomja meg és tartsa lenyomva 5 másodpercig a beállítási módba való belépéshez. A beállítási módban a kiválasztott hőmérséklet számjegye villogni fog, majd nyomja meg a beállítás gombot, így lépjen a kívánt értékre. A mentéshez nyomja meg bármelyik termék gombját.

ECO

100
90
80



Minden gomb két érintés után működik. Az első érintés csak a biztonsági zárat oldja fel. A kék jelző LED zöldre vált. Egy hangjelzést is hallani fog. A termék adagolása akkor történik meg, ha újra megérinti a termék gombot, amikor a LED zölden világít.



Visszajelző LED fény —

Aktuális meleg víz hőmérséklet —

Hideg víz —

Szódavíz —

Forró víz —



Using the faucet by touch operation panel



Cold water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified, chilled water. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.



Sparkling water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified, chilled, carbonated water. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.



Hot water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified water at the temperature of 85 °C. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.

Reheating / Settings

Use the faucet in ECO mode please.

- Press once the icon to start hot water reheating.
- Press and hold for 5 seconds to enter setting mode. In setting mode the chosen temperature digit will be blinking, then press setting once to select next temp. When needed temp is chosen press anydispensing button below to save it and leave setting mode.

ECO

100
90
80



All buttons work after two touches. The first touch unlocks the security lock only. The blue indicator LED turns green. You will also hear a beep. The product is dispensed when you touch the product button again when the LED lights green.



LED indicator light —

current hot water temperatur —

Cold water —

Sparkling water —

Hot water —

