

Az érintőgombos csaptelep használata



Hideg víz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék tisztított, hűtött vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.




Forró víz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék 85 °C-os hőmérsékletű tisztított vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.



Szódavíz. Az első érintéssel oldja fel a biztonsági zárat. Amikor a jelző LED zöldre vált, nyomja meg és tartsa lenyomva a gombot. A készülék tisztított, hűtött, szénsavas vizet adagol. Amikor elengedi a nyomógombot, az adagolás leáll. Az adagolás megkezdésekor és az adagolás leállításakor hangjelzés hallható.

Minden gomb két érintés után működik. Az első érintés csak a biztonsági zárat oldja fel. A kék jelző LED zöldre vált. Egy hangjelzést is hallani fog. A termék adagolása akkor történik meg, ha újra megérinti a termék gombot, amikor a LED zölden világít.



Using the faucet by touch operation panel



Cold water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified, chilled water. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.



Hot water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified water at the temperature of 85 °C. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.



Sparkling water. Unlock the security lock with the first touch. When the indicator LED turns green, press and hold the button. The device dispenses purified, chilled, carbonated water. When you release the push button, the dispensing stops. You will hear beep when dispensing starts and dispensing stops.

All buttons work after two touches. The first touch unlocks the security lock only. The blue indicator LED turns green. You will also hear a beep. The product is dispensed when you touch the product button again when the LED lights green.

